



Einhell

CLASSIC



Cordless Speaker

TC-SR 18 Li BT - Solo

Item No.: 4514150

Ident No.: 11019

Bar Code: 4006825644531

The Einhell TC-SR 18 Li BT - Solo cordless speaker makes it easy to connect up to all Bluetooth-enabled devices such as smart phones or tablets. In addition, the speaker has an AUX connection for connecting MP3 playery or smart phones, plus an USB connection for charging a smart phone, tablet or MP3 player. An intuitive control panel makes it easy to use. As a member of the Power-X-Change series, all the high-quality lithium-ion rechargeable batteries from the system series can be used in combination with the cordless speaker. This product comes without a battery and charger. These are available separately, for example as a practical starter set.

Features & Benefits


- A member of the Power X-Change family
- Easy connection with the device thanks to Bluetooth
- AUX connection for connecting an MP3 player, mobile phone, etc.
- USB connection for charging a mobile phone, tablet or MP3 player
- Intuitive control panel makes it easy to use
- Supplied without battery and charger (available separately)

Technical Data

- Voltage output USB	5 V
- Current output USB	2 A
- Speaker output power	2 x 3 W
- Max. loudness	85 dB (A)
- Output frequency	120 Hz - 20 kHz
- Bluetooth Version	5.0

Logistic Data

- Product weight (kg)	0.31
- Gross weight (kg)	0.38
- Dimensions single packaging	117 x 105 x 109 mm
- Pieces per export carton	12 Pieces
- Gross weight of export carton	6 kg
- Dimensions export carton	320 x 245 x 210 mm
- Container quantities (20"/40"/40"HC)	19560 39960 43032



Available as special accessories



18V 30min Power X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah PXC Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 4-6 Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory