

WD 3-18

The battery-operated WD 3-18 wet and dry vacuum cleaner with 18 V battery offers maximum flexibility thanks to its 17-litre plastic container, 2-metre suction hose, blower function and single-part cartridge filter.



Order no.

1.628-550.0

- Compact design and accessories storage, including hose storage on the device head
- Single-part cartridge filter and fleece filter bag
- Practical blower function

Technical data

Technical data		,
EAN code		4054278943572
Battery powered device		1
Battery platform		18 V battery platform
Energy use	W	225
Container capacity	I	17
Container material		Plastic
Colour		Device head / yellow / Device bumper / yellow / Container / yellow
Runtime per battery charging	min	approx. 10 (2.5 Ah) / approx. 20 (5.0 Ah)
Weight without accessories	kg	3.8
Weight incl. packaging	kg	6
Dimensions (L × W × H)	mm	349 × 328 × 492

Equipment		-
Suction hose	m	2 / with curved handle / Plastic
Removable handle		-
Suction tubes	piece(s) × m / mm	2 × 0.5 / 35 / Plastic
Wet and dry floor nozzle		clips
Cartridge filter		one-piece
Crevice nozzle		•
Fleece filter bag	piece(s)	1
Blower function		•
Parking position		
Folding carrying handle		•
Intermediate parking position of the handle on the device head		
Hose storage on the device head		
Additional accessory storage on the device head		
Accessory storage on the device		-
Sturdy bumper		
Swivel castors	piece(s)	4

Included in the scope of supply.











18 V Kärcher Battery Power exchangeable battery

- Makes it possible to work without the need for a power supply and therefore achieve maximum freedom of movement.
- Real Time Technology with LCD battery display: remaining running time, remaining charging time and battery capacity.
- Compatible with all devices in the 18 V Kärcher Battery Power platform.



Single-part cartridge filter

- For wet and dry vacuuming without filter replacement.
- Simple installation and removal of filter by turning without additional locking part.



Practical accessory storage

- Space-saving, secure and easily accessible accessories storage.
- Compact device storage.

KARCHER

ACCESSORIES FOR WD 3-18 1.628-550.0

	2	3	4	5	6	7
8	9	10	THE REAL PROPERTY AND IN THE REAL PROPERTY AND INTERPORT AND INTERPORTANTANA AND INTERPORTANTANA AND INT	12	13	14

				Τ
		Order no.	Description	
VACUUMS				
Filters				
One-piece cartridge filter KFI 3310	1	2.863-303.0	Cartridge filter for vacuuming fine and coarse dirt and liquids without having to change the filter. Suitable for Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Fleece filter bags KFI 357	2	2.863-314.0	The extremely tear-resistant KFI 357 fleece filter bags easily cope with vacuuming dry and damp dirt. Suitable for Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Accessory kits		1		
Car interior cleaning kit	3	2.863-304.0	From the footwell and the seats to the car boot: the special accessory kit for Kärcher Home & Garden wet and dry vacuum cleaners ensures uninterrupted interior car cleaning.	
Household kit	4	2.863-356.0	Handy accessory kit for switching between dry floor nozzle and upholstery nozzle. Suitable for all Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Suction brush kit	5	2.863-221.0	The suction brush kit enables thorough interior car cleaning of dashboards, foot mats, upholstered surfaces, etc., and is suitable for use on all materials. For all Home & Garden wet and dry vacuum cleaners.	
Household kit	6	2.863-002.0	The household kit contains a switchable dry floor nozzle and an upholstery nozzle. This practical accessory kit is suitable for all Kärcher Home & Garden wet and dry vacuum cleaners.	
Vacuum kit for power tools	7	2.863-112.0	Flexible suction hose (1 m) including adapter for connection to the exhaust air vent of power tools (e.g. jigsaws, grinders, drills, planes, etc.), for dirt-free DIY.	
Nozzles	·			
Extra-long crevice nozzle	8	2.863-306.0	Completely overhauled extra-long crevice nozzle. Ideal for hard-to-reach places in the car (e.g. gaps and crevices/joints). Suitable for all Kärcher Home & Garden wet and dry vacuum cleaners.	5 🗆
Car nozzle	9	2.863-316.0	Fast, effortless vacuuming guaranteed: With the car nozzle, you can clean textile surfaces in your car and around the house conveniently and thoroughly.	
Switchable wet and dry floor nozzle with integrated parking nib	10	2.863-000.0	Switchable wet and dry vacuum nozzle for perfect dirt intake. Easy adaptation to wet or dry dirt using foot switch. For all Kärcher Home & Garden wet and dry vacuum cleaners.	
Special applications				
Drill dust catcher	11	2.863-234.0	The new accessory for our wet and dry vacuum cleaners WD 2-6 allows safe and dust-free holes in conventional wall and ceiling surfaces. Drill dust is suctioned directly from the drill hole.	
Extension suction tube	12	2.863-308.0	Practical extension suction tube for greater operating range. The extension of the suction tube is recommended particularly for applications in areas that are difficult to access, such as high ceilings	
BATTERIES				
Battery Power 18/25	13	2.445-034.0	18 V / 2.5 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	
Battery Power 18/50	14	2.445-035.0	18 V / 5.0 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	

 \blacksquare Included in the scope of supply. $\hfill\square$ Available accessories. O Detergents.

KARCHER

ACCESSORIES FOR WD 3-18 1.628-550.0



		Order no.	Description
BATTERY CHARGERS		1	
Fast Charger Battery Power 18 V	15	2.445-032.0	The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power exchangeable battery to 80% in just 44 minutes and can be used for all batteries on the 18 V Kärcher battery platform.
STARTERKIT BATTERIES AND BATTERY CHARG	ERS		
Starter kit Battery Power 18/25	16	2.445-062.0	Battery Power 18/25 Starter Kit incl. 18 V/2.5 Ah Battery Power exchangeable battery with innovative Real Time Technology and 18 V fast charger. For all devices on the 18 V Kärcher battery platform.
Starter kit Battery Power 18/50	17	2.445-063.0	Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery and 18 V fast charger: The Battery [Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V battery platform.
BATTERIES		1	
Battery Power+ 18/30	18	2.445-042.0	With Real Time Technology displayed on an LCD screen: very powerful Battery Power+ 18-volt [lithium-ion battery. Long runtime thanks to a capacity of 3.0 Ah. With voltage monitoring and IPX5 protection.

■ Included in the scope of supply. □ Available accessories. ○ Detergents.