

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](http://arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](http://arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity, visit [www.arlo.com/about/regulatory/](http://www.arlo.com/about/regulatory/).



Arlo Technologies Intl. Ltd.  
Ground Floor, Building 3  
University Technology Center  
Curraheen Road, Cork, T12 EF21  
Ireland



Arlo Technologies, Inc.  
2200 Faraday Avenue, Suite 150  
Carlsbad, CA 92008 USA

December 2019



## Set up your Arlo Pro 3 Wire-Free camera

1. Connect the power adapter and the Ethernet cable to your Arlo SmartHub.
2. Download the Arlo app and follow the setup instructions for a wire-free camera.
3. Insert the battery into your wire-free camera.



## What's in the box

---



Arlo SmartHub



Pro 3 Wire-Free  
Camera



Rechargeable  
battery



SmartHub  
power adapter



Ethernet cable



Mounts



Camera  
power adapter



Camera  
charging cable

## Need help?

---

We are here for you.

Visit [www.arlo.com/support](http://www.arlo.com/support) for quick answers and resources:

- How-to videos
- Troubleshooting tips
- The Arlo Support phone number for your location