



Einhell

CLASSIC



Cordless Scarifier / Aerator

GC-SC 36/31 Li-Solo

Item No.: 3420660

Ident No.: 11018

Bar Code: 4006825636956

The Einhell Cordless Scarifier GC-SC 36/31 Li-Solo is a professional lawn care tool. It is recommended for lawns up to 300 m². As a member of the Power X-Change family, the batteries fit all products in this range. Two 18 V batteries power the series-wound motor. The eight double blades are mounted on the ball bearing-mounted blade cylinder, which is made of sturdy stainless steel. The working depth can be adjusted to three levels and to a transport position. The handle is height-adjustable and foldable. The large wheels protect the lawn, and the housing is made of impact-resistant plastic. The GC-SC 36/31 Li can be optionally upgraded to a 3-in-1 combination tool (aerator shaft/collection basket). Supplied without batteries or a charger.

Features & Benefits


- Member of the Power X-Change family, 2x18V batteries necessary
- Powerful series motor
- Ball-bearing scarifier drum with 8 stainless steel double-knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 300 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag

Technical Data

- Number of knives 8 Pieces
- Wheel diameter front 18 cm
- Wheel diameter rear 10 cm

Logistic Data

- Tool weight 10 kg
- Gross Weight 12 kg
- Dimensions single packaging 600 x 460 x 330 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 12 kg
- Dimensions export carton 600 x 460 x 330 mm
- Container quantity (20"/40"/40"HC) 320 | 670 | 765



Available as special accessories



Lüfterwalze GC-ES/SA 1231/1
Scarifier Accessory
Item No.: 3405572
Bar Code: 4006825629675
Einhell Accessory



Messerwalze GC-ES/SA 1231/1
Scarifier Accessory
Item No.: 3405582
Bar Code: 4006825629682
Einhell Accessory



Fangsack GC-ES/SA 1231/1
Scarifier Accessory
Item No.: 3405577
Bar Code: 4006825629699
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 30min Power-X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory