



BLINDER




QUICKSTART GUIDE

RECHARGE BEFORE FIRST USE



RECHARGE BEFORE FIRST USE



USB PLUG

INTERFACE



- A. LOW BATTERY INDICATOR
- B. POWER/MODE SWITCH
- C. RECHARGE INDICATOR

LONG PRESS B TO TURN LIGHT ON/OFF
SHORT PRESS B TO CYCLE MODES

FITMENT
3 STRAP SIZES
INCLUDED

S

M

L

**BLINDERS COME PRE-FITTED
TO CLASP WITH MEDIUM STRAP**

INTERCHANGEABLE STRAP



STRETCH STRAP TO FIT CLASP




PLACE STRAP END OVER HOOK



PULL STRAP TOWARD
THE LIGHT BODY

MOUNTING



1. PULL SILICONE STRAP AROUND BAR
2. ENGAGE LATCH INTO HOOK

THE RANGE



WARRANTY INFORMATION

2 YEARS WARRANTY ON MATERIALS
AND WORKMANSHIP

6 MONTHS BATTERY WARRANTY
AGAINST MANUFACTURING DEFECTS
ONLY. NOT INCLUDING BATTERY
DETERIORATION.



ENGLISH Please visit knog.com.au for more information and updates.

FRANÇAIS Rendez-vous sur le site knog.com.au pour plus d'informations et pour les mises à jour.

ESPAÑOL Por favor, visite knog.com.au para más información y actualizaciones.

ITALIANO Si prega di visitare knog.com.au per ulteriori informazioni e aggiornamenti.

DEUTSCH Mehr Informationen und Updates auf knog.com.au

日本語 最新の情報は、Knogのホームページにてご確認ください。