



TSP-353
Denver.eu
2022

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Warning: This product includes lithium ION battery.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Do not expose to heat, water, Dust (dusty environment), moisture, direct sunlight!
7. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
8. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
9. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
10. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
11. Only charge with supplied USB cable.
12. Do not use non original accessories together with the product as this can make the product functionality abnormal.
13. Do not block the devices ventilation. Product should be able to disperse the heat.

CHARGING INSTRUCTIONS

1. When you hear a low battery warning sound, it means that the product enters low

power state and needs to be charged. The volume of the product will automatically drop to about 70% of the main volume, and the light will turn off automatically. To charge the product's battery, use the charging cable delivered with the product. The charging indicator will glow red when charging and will be off when fully charged.

2. Note that the current of the 10V charger should be greater than 1A.
3. Note: The battery must be charged for more than 12 hours before first use. If the battery does not work for a long time, it must be fully charged to avoid battery damage.

Information published	Value and precision
Manufacturer's name or trade mark, commercial registration number and address	SHENZHEN GUIJIN TECHNOLOGY CO. 301.NO.72,SONGXIN INDUSTRIAL, HONGXING CCOMMUNITY,SONGGANG STREET,BAO AN,SHENZHEN
Model identifier	AK12WG-1000100VW
Input voltage	100 - 240 V
Input AC frequency	50/60 Hz
Output voltage (adaptor)	10.0V
Output current (adaptor)	1.0A
Output power	10.0W
Average active efficiency	82.2%
Efficiency at low load (10 %)	81.43%
No-load power consumption	0.054W

FUNCTION DESCRIPTION

General functions

1. Mode switchover button: Press to switch mode.
2. Master volume: during playback of songs, clockwise rotation to increase volume, counterclockwise to decrease volume.
3. Microphone volume: effective when the microphone is inserted; adjust the volume of the microphone.
4. Microphone reverb volume: effective when the microphone is inserted; adjust the intensity of the microphone reverb by increasing or decreasing the reverb volume.
5. Bass adjustment: clockwise rotation to increase bass, counterclockwise to decrease bass.
6. Treble adjustment: clockwise rotation to increase treble, counterclockwise to decrease treble.
7. Light control: press the Light button to switch the light effect.

MP3 Function

1. USB disk: Insert a USB disk to automatically play the saved songs in MP3\WAV format.
2. TF card: Insert a TF card to automatically play the saved songs in MP3\WAV format.
3. Play/Pause button: Press to pause/resume playback of a song.
4. Previous Song/Next Song buttons: press to play the previous or next track, press and hold to rewind or fast-forward.
5. EQ: Normal-Rock-Pop-Classic-Jazz-Country
6. EQ button: Press EQ button during playback to switch between different music modes: Normal-Rock-Pop-Classic-Jazz-Country.


Bluetooth Function

1. Bluetooth connection: The speaker will automatically enter the pairing waiting state after it enters Bluetooth mode. Turn on the Bluetooth feature on your device (e.g., smartphone, tablet or computer), select device name "TSP-353" and click Pairing.
2. When playing music: press the Play/Pause button, Previous Song/Next Song buttons to control the playback.
3. Manual pairing: To pair the speaker with another device, hold down the Play/Pause button to disconnect the speaker from the currently connected device and enter the pairing waiting state again.

TWS Function

1. Please purchase 2pcs TSP-353 speaker if you want to use TWS function. Turn on one of the speakers, connect the speaker via Bluetooth to your devices.
2. Turn on the second speaker, then press and hold Previous Song button. You will hear a "Beep" sound when the devices are connected in TWS mode.
3. To disable TWS mode, press and hold Next Song button on the first speaker. You will hear a short "Beep" sound when the devices are disconnected from TWS.

CONTROL PANEL DESCRIPTION



- | | |
|---------------------------|------------------------------------|
| 1. Mic 1 | 13. Master volume+/- /Power switch |
| 2. Mic 2 | 14. Microphone volume+ |
| 3. Line Out | 15. Microphone reverb volume+ |
| 4. AUX In | 16. Microphone volume- |
| 5. TF card | 17. Microphone reverb volume- |
| 6. USB PORT | 18. Mode button |
| 7. Charging indicator LED | 19. Bass |
| 8. DC 10V input | 20. Treble |
| 9. EQ button | 21. Light button |
| 10. Previous Song | |
| 11. Play/Pause | |
| 12. Next Song | |



Warning!

- Lithium battery inside!
- Do not open the product!
- Do not expose to heat, water, moisture or direct sunlight!
- Only charge with the original charger supplied with this product!



1. DO NOT place objects on top of the device, as objects may scratch the device.



2. DO NOT expose the device to dirty or dusty environments.



3. DO NOT insert any foreign objects into the device.



4. DO NOT expose the device to strong magnetic or electric fields.



5. DO NOT use the device in the rain.



6. Please check with your Local Authority or retailer about the proper disposal of electronic products.



7. DO NOT disassemble the device. Only a certified service technician could perform a repair.



Warning: Lithium batteries inside

8. The device has apertures to disperse heat.

DO NOT block the device ventilation, otherwise the device may become hot and malfunction as a result. Illegal operations may cause personal injuries, property damage, or fatal accidents.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type TSP-353 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is

available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: TSP-353. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range:60Hz-20KHz

Max Output Power:300W (30W RMS)

DENVER A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu